



More information on the website
mirror.radwag.com/us/info,w1,10R

PT0022 Cable



The drawings, photos and graphics used are for illustrative purposes only.

Overview

RS 232 cable for connecting a balance/scale (PUE C/41H, PUE HY10, PUE 5 indicator) to a ZEBRA printer.

Standard cable length: 2m

Customized cable length (extra charge): 5 or 10m

Compatible with:

- Scales operated by means of PUE C41H terminal
- Scales operated by means of PUE 5.15 (5.19) terminal
- Scales operated by means of PUE HY10 terminal
- PUE C41H terminal
- PUE 5.15 (5.19) terminal
- PUE HY10 terminal

Compatible with

HX7 H Multifunctional Scale
HX7.4N H Multifunctional Stainless Steel Ramp Scale
HX7.4C Multifunctional Platform Scale
HX7 HR Multifunctional Scale

HX7.4 H/Z Multifunctional Stainless Steel Platform Scale, pit version
HX7.4 H Multifunctional Stainless Steel Platform Scale
HX7.4P2 Multifunctional Beam Scales
HY10.H scales for PGC

HY10.HRP.H High Resolution Scale
HX7.4P2 H Multifunctional Stainless Steel Beam Scales
TMX H Stainless steel Multifunctional Scale
TMX Multifunctional Scale
HX7.4N H.LD Multifunctional Stainless Steel Ramp Scale
DWT/RC/HYF Checkweighers
HX7.4P H Multifunctional Stainless Steel Pallet Scales
HY10 Multifunctional Scale
HY10 H Stainless Steel Multifunctional Scale
HY10.HRP High Resolution Scale
HX7 Multifunctional Scale

PUE C32 Weighing Terminal
PUE HX7 Weighing Terminal
PUE 5 Weighing Terminal
Rotational Control Scales
Label Printers
DWM H2 Checkweighers
HX7.4P Multifunctional pallet scales
DWM Checkweighers
Control Scales for Large Loads
Roller Scales