



More information on the website
mirror.radwag.com/en/info,w1,4LG

PT0287 Cable



The drawings, photos and graphics used are for illustrative purposes only.

Overview

The PT0287 cable is an RS232 cable that connects the RTP-RU80 printer to scales equipped with an RS232 connector (DB9 M). These are the WTC and WLC scales and scales featuring the PUE C315, PUE C32, and PUE 7.1 indicators and terminals. The standard length of the PT0232 cable is 1.7 m.

Compatible with

WPY Multifunctional Scale
 C32 Multifunctional Scale
 C315 Platform scale
 WLY Scales for PGC
 C315.D Baby Scale
 WLC Precision Balance
 C315.4P2 Beam Scales
 WLC X7 Precision Balance
 PUE 7.1.HRP High Resolution Scale
 C315.4 Platform Scale
 C32.PM Precision Balance
 C315.O Personal Scale
 WPY Scales for PGC
 C315.4P pallet scales

WTC Precision Balance
 C315.OW Personal Scale
 WLY Precision Balance
 WLC C/2 Precision Balance
 PUE C32 Weighing Terminal
 PUE 7.1 Weighing Terminal
 Postal Scales for Packages
 PUE C315 Weighing Terminal
 H315 H Waterproof Platform Scale
 C315.4B Bed Scale
 C315.K Chair Scale
 C315.8B Ramps Bed Scale
 Receipt Printer

