



More information on the website  
[mirror.radwag.com/en/info,w1,4LG](http://mirror.radwag.com/en/info,w1,4LG)

## PT0287 Cable

WX-013-0226



The drawings, photos and graphics used are for illustrative purposes only.

## Overview

The PT0287 cable is an RS232 cable that connects the RTP-RU80 printer to scales equipped with an RS232 connector (DB9 M). These are the WTC and WLC scales and scales featuring the PUE C315, PUE C32, and PUE 7.1 indicators and terminals. The standard length of the PT0232 cable is 1.7 m.

## Compatible with (Additional Fee)

WPY Multifunctional Scale  
 C32 Multifunctional Scale  
 C315 Platform scale  
 WLY Scales for PGC  
 C315.D Baby Scale  
 WLC Precision Balance  
 C315.4P2 Beam Scales  
 WLC X7 Precision Balance  
 PUE 7.1.HRP High Resolution Scale  
 C315.4 Platform Scale  
 C32.PM Precision Balance  
 C315.O Personal Scale  
 WPY Scales for PGC  
 C315.4P pallet scales

WTC Precision Balance  
 C315.OW Personal Scale  
 WLY Precision Balance  
 WLC C/2 Precision Balance  
 PUE C32 Weighing Terminal  
 PUE 7.1 Weighing Terminal  
 Postal Scales for Packages  
 PUE C315 Weighing Terminal  
 H315 H Waterproof Platform Scale  
 C315.4B Bed Scale  
 C315.K Chair Scale  
 C315.8B Ramps Bed Scale  
 Receipt Printer

