



More information on the website
mirror.radwag.com/en/info,w1,4LG

PT0287 Cable



The drawings, photos and graphics used are for illustrative purposes only.

Overview

The PT0287 cable is an RS232 cable that connects the RTP-RU80 printer to scales equipped with an RS232 connector (DB9 M). These are the WTC and WLC scales and scales featuring the PUE C315, PUE C32, and PUE 7.1 indicators and terminals. The standard length of the PT0232 cable is 1.7 m.

Compatible with

WPY Multifunctional Scale
C32 Multifunctional Scale
C315 Platform scale
WLY Scales for PGC
C315.D Baby Scale
WLC Precision Balance
C315.4P2 Beam Scales
WLC X7 Precision Balance
PUE 7.1.HRP High Resolution Scale
C315.4 Platform Scale
C32.PM Precision Balance
C315.0 Personal Scale
WPY Scales for PGC
C315.4P pallet scales

WTC Precision Balance
C315.0W Personal Scale
WLY Precision Balance
WLC C/2 Precision Balance
PUE C32 Weighing Terminal
PUE 7.1 Weighing Terminal
Postal Scales for Packages
PUE C315 Weighing Terminal
H315 H Waterproof Platform Scale
C315.4B Bed Scale
C315.K Chair Scale
C315.8B Ramps Bed Scale
Receipt Printer

